SAMSUNG

3 CD DVD CHANGER KARAOKE MINI MINI COMPONENT

MAX-KD100/110/120
MAX-KDZ100/110/120

SERVICE Manual

MINI MINI COMPONENT SYSTEM



CONTENTS

1. Alignment and Adjustments
2. Exploded Views and Parts List
3. Electrical Parts List
4. Block Diagrams
5. PCB Diagrams
6. Wiring Diagram
7. Schematic Diagrams
8. Troubleshooting

Notice !!

You can search for the updated part code through ITSELF web site.
URL; http://itself.sec.samsung.co.kr

- Confidential -

ELECTRONICS

This Service Manual is a property of Samsung Electronics Co.,Ltd.
Any unauthorized use of Manual can be punished under applicable international and/or domestic law.

© Samsung Electronics Co.,Ltd. MAR. 2003
Printed in Korea
Code no. AH68-01322A